


H4-650 Copter Assembly

All spare parts are include as follows




Firstly, you need to prepare the hex driver and socket by yourselves




H2.5 Hex driver 4 in 1; 5.5 box socket

1. Main frame assembly




upper plate X1pcs; bottom plate X1pcs; M3*18 screws X16pcs; M3 screws nut X28pcs




Twist well the M3 screws and nuts to fix the main frame

2. Controller board assembly



M3 hex Nylon spacers X12pcs; M3 Nylon screws X24pcs; cover boards X3pcs




Nylon spaces and screws are soft and elastic, please fix them carefully


3. Motor mount& arms assembly



207mm alu tubes X4pcs; motor mount X4pcs; M3*8 screws&nut X8sets; green stickers X4pcs



4. Arms fixed to frame assembly



Main frame X1pcs; arms X4pcs; M3*18 screws X16pcs; M3 nuts X16pcs



Arms can be fold freely before fixing the inner 4pcs screws, please fix the screws well when flying.

5. Landing gear assembly

